



## SPA CARE GUIDE

Use this guide to understand and simplify your spa care Start-Up and maintenance

**Knowing your gallonage is key:**  
My Spa Gallonage is \_\_\_\_\_

### Spa Volume Calculator



#### Rectangular Shape Spa:

$(Length \times Width \times Average Depth) \times 7.5$

#### Round & Oval Shaped Spas:

$(Length \times Width \times Average Depth) \times 5.9$

## ALWAYS REMEMBER THESE IMPORTANT PRECAUTIONS

- Read all product labels to understand their directions & precautions.
- Never add chemicals to the spa while people are in it.
- Always add chemicals to water **NEVER** water to chemicals.
- Never mix multiple chemicals together in the same container.
- Store all chemicals as directed in a cool, dry location out of direct sunlight.
- Do not add chemicals directly to the skimmer unless label specifically instructs you to do so.

## SPA START-UP

### In A Clean Operational Spa

**Step 1:** Establish a bromine base in the spa. Use two ounces Sodium Bromide per 500 gallons of water. Add one half capful of O-ACE-sis® Yellow Eliminator (Powdered Sodium Bromide).

**Step 2:** Shock the spa with our non-chlorine shock O-ACE-sis® No-Chlor which helps activate the bromine.

**Step 3:** While our spa is now ready to enjoy, we use Bromine tablets to maintain proper levels of Bromine. Keep in mind that the tablets are to maintain a consistent Bromine residual but they will not produce an instant base needed.

## START DAILY SANITIZER ROUTINE

## HANDY CALCULATIONS

**After any adjustment circulate 20 minutes and retest.**  
**Each dosage is per 500 gallons**

- 1oz of O-ACE-sis® Calcium Hardness Increaser will raise Calcium Hardness 10ppm.
- Use two heaping tablespoons of O-ACE-sis® pH Minus to lower pH and/or Alkalinity, retest.
- Use two heaping tablespoons of O-ACE-sis® Alkalinity Increaser to raise Alkalinity, retest.
- 1oz of O-ACE-sis® Metal Out Plus followed by 1oz of O-ACE-sis® Natural Clarifier will help eliminate metals and clouding particulates suspended in the water.
- 2oz of Sodium Bromide (O-ACE-sis® Yellow Eliminator) is adequate to establish a Bromine base.

**Regularly Test & Maintain These Levels**  
**SANITIZER**  
3-5 ppm  
**pH**  
7.2 - 7.8  
**CALCIUM HARDNESS**  
200-300 ppm  
**TOTAL ALKALINITY**  
80-120 ppm  
**COPPER & IRON**  
< .6 ppm

## PREVENTIVE MAINTENANCE

**Follow these steps to save TIME & MONEY**

**Daily:** Test & Maintain 3-5 ppm sanitizer & maintain a pH range of 7.2 to 7.6  
Spas should be circulated regularly even while not in use.

**Weekly:** Test & Maintain Total Alkalinity at 80-120 ppm

**Monthly:** Maintain Calcium Hardness at 200-300 ppm.  
Test Copper & Iron Levels & use O-ACE-sis® Metal Out Plus® if levels are above .6 ppm. Follow up with O-ACE-sis® Natural Clarifier

**1-3 Months:** Depending on how frequently you use your spa, you may need to change your water more or less often. Heavy bather loads, any fecal contamination, or an unclean appearance will make it necessary to replace the water.  
If the surface of the spa needs cleaning, do so with a bleach solution, rinse well before refilling. Remember to follow start up and balancing procedures.

